

TIMER OPERATING INSTRUCTIONS



1. To set the time, hold down the CLOCK Key while pressing either the HOUR or MINUTE keys. Continue pressing until the desired number is shown. Then simply lift finger off the CLOCK Key to set.
2. To Set Program (ON/OFF) times: Press the TIMER Key once to enter into program mode. Display will show "1 ON-- --".
3. Press the HOUR Key and then the MINUTE Key to select the desired first OFF time. Repeat the entire sequence to complete up to eight ON/OFF times as desired.
4. When programming is done, press the CLOCK Key then the SELECT Key repeatedly until the indicator bar is above the word "AUTO".

**CAUTION: DISCONNECT ALL POWER BEFORE SERVICING
DO NOT INSTALL OR OPERATE IN SWIMMING AREAS**



OPERATING CONDITIONS

OPERATE UNIT ONLY IN FRESH WATER WITH WATER TEMPERATURE NOT EXCEEDING 40OC. DO NOT OPERATE IN SWIMMING AREAS.

1. Make sure the timer is set to the proper time on the front dial of the timer. Set the on-off sequence to turn the fountains on and off at the desired time.
2. Turn on supply disconnect which is located on the right side of the panel.
3. Turn on the Residual Current Operator. Test to make sure that this safety device works properly. Press the test button and the breaker should trip. If it does not trip, check for proper wiring or defective device.

NOTE: DO NOT BYPASS THIS SAFETY DEVICE. THIS DEVICE MUST BE TESTED EVERY MONTH.

4. Reset the breaker.
5. Sit back and enjoy your fountain/aerator.

CAUTION: DISCONNECT ALL POWER BEFORE SERVICING