

EUTROSORB® WC

Water Column Phosphorus Inactivator

KEEP OUT OF REACH OF CHILDREN

Read all FIRST AID and PRODUCT HANDLING directions on label before use.

FIRST AID	
If in eyes:	Remove contaminated clothing. Immediately rinse skin with water for 15 to 20 minutes. Seek medical attention if irritation persists.
If on skin or clothing:	 Remove contaminated clothing. Immediately rinse skin with water for 15 to 20 minutes. Seek medical attention if skin irritation persists.
If inhaled:	Immediately move to fresh air; if person is not breathing, call 911 or an ambulance, then give artificial respiration.
If swallowed:	Do not induce vomiting unless instructed todo so by a doctor.
HOTLINE NUMBER	

Have the product container or label with you when calling a poison control center or doctor or going for treatment. You may also contact INFOTRAC for emergency medical information 1-800-535-5053.

PRODUCT INFORMATION:

EutroSORB® WC is a proprietary solution developed specifically for rapid and stable inactivation of phosphorus from the water column of a variety of water bodies such as lakes, reservoirs, ponds, rivers, streams, canals, ditches, etc. EutroSORB® WC is a high performance, water-soluble phosphate binder that does not stain equipment or features.

DIRECTIONS FOR USE

Read all Direction for Use carefully before applying this product. See EutroSORB® WC product use guide for additional information.

Obtain Required Permits: Consult with appropriate state or local water authorities before applying this product in or around public waters.

APPLICATION INFORMATION

This product can be directly applied to or injected in surface waters and can be used in or around public waters.

For best results, distribute EutroSORB WC uniformly over the surface of the waterbody or the area targeted for phosphorus inactivation. When making applications to flowing waters (e.g., rivers, streams, ditches, etc.), drip or inject EutroSORB WC at a location where adequate mixing occurs to optimize phosphorus binding.

EutroSORB®WC

The phosphorus binding of this product will depend on water quality parameters and site-specific conditions. Please consult a SePRO Technical Specialist for guidance in implementing a treatment program to achieve optimal results.

For site specific rate and treatment recommendations, contact **your SePRO Technical Specialist or SePRO Corporation** at**1-800-419-7779**.

PDU Dosage Rate details

Apply 10 PDUs of EutroSORB WC to inactivate 1 lb. of phosphorus from the water column.

PRODUCT HANDLING

Precaution: Avoid contact with eyes and skin. Avoid ingestion and inhalation. Wear impermeable gloves and eye protection when handling. Do not apply this product in a way that concentrate will contact workers or other people, either directly or through drift. This material is not expected to be harmful to fish or aquatic invertebrates.

Storage and Disposal: Store in the original container and keep closed. Store away from and not mixed with oxidizers. Thoroughly rinse the container with treated water before disposal. Offer for recycling if available.

Warranty Disclaimer: SePRO Corporation warrants that testing and research have determined this product is reasonably fit for the uses described on the product label. To the extent consistent with applicable law, SePRO Corporation makes no other express or implied warranty of fitness or merchantability nor any other expressor implied warranty and any such warranties are expressly disclaimed.

Misuse: Federal law prohibits the use of this product in a manner inconsistent with its label directions. To the extent consistent with applicable law, the buyer assumes responsibility for any adverse consequences if this product is not used according to its label directions. To the extent consistent with applicable law, in no caseshall SePRO Corporation be liable for any losses or damages resulting from the use, handling or application of this product in a manner inconsistent with its label.

For additional important labeling information regarding SePRO Corporation's Terms and Conditions of Use, inherent Risks of Use and Limitations of Remedies, please visit http://seprolabels.com/terms or scan the image below.



FPL 20220125

SePRO Corporation 11550 North Meridian Street, Suite 600, Carmel, IN 46032 U.S.A. EutroSORB is a registered trademark of SePRO Corporation.

©Copyright 2022 SePRO Corporation